

















Product benefits

 PVC-free	 Fire-retardant	 Nonwoven adhesive	 Paste-the-wall technique	 Breathable
 Impact-resistant	 Outstanding light-fastness	 Easy to remove	 Latex inks	 Solvent inks
 UV inks	 UV resistance	 Environmentally-friendly	 Fire protection classification	

How to use



1. Remove old wallpaper and paint. Smooth out rough base surfaces with plaster-based filler. Prime very absorbent base surfaces with solvent-free primer.



2. Ensure that the base surface is dry, clean, firm, absorbent and smooth. Mark the width of the wallcovering on the wall as a vertical line to aid hanging the first length perpendicular to the floor.



3a. Use nonwoven adhesive in a ratio of 1:10. Use a pasting machine without soaking or



3b. Use with the paste-the-wall technique – no soaking.



4a. Butt the lengths together where the edges of the print are cut cleanly or



4b. Where the lengths of wallpaper are printed with an overlap, cut off the white margins as far as the image when dry. Then align the lengths on the wall where they overlap. Make a cut through both layers for a clean join.



5. Use a sponge roller to smooth down the wallpaper.



6. Use a soft, moist and clean cloth to carefully wipe away any paste that oozes out from the individual lengths.



7. Cut off excess wallpaper in the corners with a wallpapering palette knife and a Stanley knife or with scissors.



8. Remove any slight traces of paste with a soft, slightly moist cloth.



9. When you come to redecorate, the wallpaper can be removed with ease.



Product Description

ERFURT-Digitalvlies DV

Manufacturer

Erfurt & Sohn KG • Hugo-Erfurt-Straße 1
42399 Wuppertal • www.erfurt.com

Raw materials/Manufacture

ERFURT-Digitalvlies DV is a durable, PVC-free wallcovering with a pre-coated finish suitable for digital ink jet printing, manufactured from special cellulose and textile fibres, combined with polymer binding agents.

Product data

- Digitalvlies DV 615, DV 617, DV 635, DV 638
- Roll dimensions: 40.00 m long x 0.75 m wide
- Weight: approx. 220 g/m²
- Digitalvlies DV 662/00
- Roll dimensions: 40.00 m long x 0.75 m wide
- Weight: approx. 220 g/m²
- Digitalvlies DV 662/01
- Roll dimensions: 50.00 m long x 1.50 m wide
- Weight: approx. 220 g/m²

Product features

- Smooth or textured, hot embossed surface
- Its water vapour permeability as per DIN 52615 corresponds to a diffusion-equivalent air layer thickness of approx. 0.05 m.
- Fire rating „C-s1,d0“ according to EN 13501-1 corresponds to „C1“ (fire retardant) according to DIN 4102-1
- Free of PVC, plasticisers and solvents harmful to health
- Fibreglass-free
- No addition of heavy metal compounds or formaldehyde
- Dimensionally stable and covers cracks (Class A)
- Excellent base surface coverage due to the pigmentation in the wallpaper
- Easy to remove after moistening with water

Printing properties

- Up to 30% less ink used
- Printable with solvent-based, latex and UV-cured inks
- Suitable for eco-friendly digital printing

ERFURT-Digitalvlies DV

- Certified according to Oeko-Tex® Standard 100 Product Class IV printed with HP latex inks



Application/Handling

ERFURT-Digitalvlies DV can be used on all interior base surfaces suitable for wallpapering. Ensure that the base surface is carefully prepared and dry, clean, firm, slightly absorbent and smooth.

Remove old wallpaper and loose paint. Smooth out rough base surfaces with plaster-based filler. Prime very absorbent base surfaces with solvent-free primer. Please read BFS data sheets nos. 7 and 16.

Depending on the printing technique, the print can overlap 10-15 mm or not overlap where the cutting edge is clean.

Base surface

Ensure that the base surface is dry, firm, even, absorbent, clean, smooth and sufficiently flat for the intended wallcovering. Remove old wallpaper and loose paint. Smooth out rough base surfaces with plaster-based filler. Prime smooth plaster with diluted paste. Prime heavily absorbent base surfaces using solvent-free primers. Even absorbency is important when using the paste-the-wall technique.

Adhesion

The method used for ERFURT-Digitalvlies DV depends on the printing technique used. Always hang perpendicular. We recommend hanging it „away from light“.

Butt joints

The lengths can be butted together where the edges of the print are cut cleanly.

Hanging with a double seam cut

Where the lengths of wallpaper are printed with an overlap, cut off the white margins as far as the image when dry. Then align the lengths on the wall where they overlap and use a rubber roller or wallpapering palette knife to smooth out the bubbles. Make a cut through both layers for a clean join, remove any residual wallpaper and paste and gently finish with a seam roller.

Press excess lengths at ceilings, skirtings, windows etc. into the corners with a straight edge and cut off with a Stanley knife. Ensure that the wallcovering does not overlap. **Use a soft, lightweight and moist cloth to immediately remove any traces of paste on the surface.**

ERFURT-Digitalvlies DV wallcoverings are highly resistant. We would recommend protecting the print after wallpapering with a high-quality clear coating (e.g. Disbopur 458 PU Aqua Seal) in areas that will be exposed to high levels of use, for example hotels and restaurants, swimming pools and event areas.

Using the paste-the-wall technique

Use nonwoven adhesive (e.g. Metylan segura/Metylan NP New Plaster Paste at a ratio of 1:10 = 1000 g in 10 litres of water) or similar to paste the paper. Apply the adhesive evenly to the base surface and place the cut lengths dry into the bed of adhesive. Please read the adhesive manufacturer's instructions for use.

Using a pasting machine

Paste ERFURT-Digitalvlies DV using a pasting machine, fold it and hang it immediately without soaking. Use nonwoven adhesive (e.g. Metylan segura/Metylan NP New Plaster Paste at a ratio 1:10 = 1000 g in 10 litres of water) or similar to paste the paper. Please read the adhesive manufacturer's instructions for use.

Made in Germany

Erfurt & Sohn KG
Hugo-Erfurt-Straße 1
D-42399 Wuppertal

Phone.: +49 202 61 10-0
Fax: +49 202 61 10-89 451

E-mail: info@erfurt.com
Website: www.erfurt.com

Service line:
+49 202 61 10-375

